



2D Rigid-Body Motions and Rotation Matrices

CS 6301 Special Topics: Introduction to Robot Manipulation and Navigation

Professor Yu Xiang

The University of Texas at Dallas


Rigid-Body Motions



<https://venturebeat.com/ai/mit-csail-refines-picker-robots-ability-to-handle-new-objects/>


Vectors and Reference Frames

- A **free vector**: a geometric quantity with a length and a direction
 - An arrow in \mathbb{R}^n , not rooted anywhere
 - E.g., a linear velocity
- A free vector in a reference frame
 - The base of the arrow at the origin
 - Coordinates in the reference frame $v \in \mathbb{R}^n$
 - Coordinates change with reference frames
 - The underlying free vector does not change (coordinate free)



Points

- A point in space can be represented as a vector




More about Reference Frames


- A reference frame can be attached anywhere
- Different reference frames result in different representations of the space and objects, but the underlying geometry is the same
- Always assume one stationary **fixed frame** or **space frame** {s}
 - E.g., a corner of a room
- **Body frame** {b} is the stationary frame coincident with the body-attached frame at any instance
 - E.g., origin on the center of mass of the body

More about Reference Frames

- All frames in this course are stationary
- All frames in this course are right-handed



Rigid-Body Motions in the Plane



- Configuration of the planer body
 - Position and orientation with respect to the fixed frame
- Body frame origin in the fixed frame

$$p = p_x \hat{x}_s + p_y \hat{y}_s$$
$$p = (p_x, p_y) \text{ Vector form}$$


- Rotation angle θ
- Directions of the body frame

$$\hat{x}_b = \cos \theta \hat{x}_s + \sin \theta \hat{y}_s,$$

$$\hat{y}_b = -\sin \theta \hat{x}_s + \cos \theta \hat{y}_s$$

Rigid-Body Motions in the Plane

- The two axes of the body frame in {s}



$$P = [\hat{x}_b \ \hat{y}_b] = \begin{bmatrix} \cos \theta & -\sin \theta \\ \sin \theta & \cos \theta \end{bmatrix} \quad \text{Write as column vectors}$$


Rotation matrix

1DOF

$$p = \begin{bmatrix} p_x \\ p_y \end{bmatrix} \quad \text{Translation}$$

(P, p) specifies the orientation and position of {b} relative to {s}

Rigid-Body Motions in the Plane



- {c} in {s}

$$r = \begin{bmatrix} r_x \\ r_y \end{bmatrix}, \quad R = \begin{bmatrix} \cos \phi & -\sin \phi \\ \sin \phi & \cos \phi \end{bmatrix}$$

- {c} in {b}


$$q = \begin{bmatrix} q_x \\ q_y \end{bmatrix}, \quad Q = \begin{bmatrix} \cos \psi & -\sin \psi \\ \sin \psi & \cos \psi \end{bmatrix}$$

- With {b} in {s} and {c} in {b}

$$R = PQ \quad (\text{convert } Q \text{ to the } \{s\} \text{ frame})$$

$$r = Pq + p \quad (\text{convert } q \text{ to the } \{s\} \text{ frame and vector-sum with } p)$$

Rigid-Body Motions in the Plane



- Two frames attached to a rigid body $\{d\} \{c\}$
- Initially, $\{d\} = \{s\}$, $\{c\}$ in $\{s\}$ by (R, r)
- Now, $\{d\}$ move to $\{b\}$ (P, p) in $\{s\}$
- Where dose $\{c\}$ end up?

$$R' = PR,$$

$$r' = Pr + p.$$


(P, p) is expressed in the same frame as (R, r)

not viewed as a change of coordinates


Known as a rigid-body motion

A Rotation Matrix-Vector Pair (P, p)


- Represent a configuration of a rigid body in $\{s\}$




- Change the reference frame




- Displace a vector or a frame



Rigid-Body Motions in the Plane



Rotation followed by translation



Rotation about a fixed point s by β **Screw motion**
 three screw coordinates (β, s_x, s_y)

Rigid-Body in 3D

$$p = \begin{bmatrix} p_1 \\ p_2 \\ p_3 \end{bmatrix}$$

- Origin of the body frame


$$p = p_1 \hat{x}_s + p_2 \hat{y}_s + p_3 \hat{z}_s$$

- Axes of the body frame

$$\hat{x}_b = r_{11} \hat{x}_s + r_{21} \hat{y}_s + r_{31} \hat{z}_s,$$

$$\hat{y}_b = r_{12} \hat{x}_s + r_{22} \hat{y}_s + r_{32} \hat{z}_s,$$

$$\hat{z}_b = r_{13} \hat{x}_s + r_{23} \hat{y}_s + r_{33} \hat{z}_s.$$



$$R = [\hat{x}_b \quad \hat{y}_b \quad \hat{z}_b] = \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix}$$

Rotation matrix

Write as
column
vectors

Rotation Matrix

- Unit norm condition

$$r_{11}^2 + r_{21}^2 + r_{31}^2 = 1,$$

$$r_{12}^2 + r_{22}^2 + r_{32}^2 = 1,$$

$$r_{13}^2 + r_{23}^2 + r_{33}^2 = 1.$$

$$R = [\hat{x}_b \ \hat{y}_b \ \hat{z}_b] = \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix}$$

- Orthogonality condition $\hat{x}_b \cdot \hat{y}_b = \hat{x}_b \cdot \hat{z}_b = \hat{y}_b \cdot \hat{z}_b = 0$

$$r_{11}r_{12} + r_{21}r_{22} + r_{31}r_{32} = 0,$$

$$r_{12}r_{13} + r_{22}r_{23} + r_{32}r_{33} = 0,$$

$$r_{11}r_{13} + r_{21}r_{23} + r_{31}r_{33} = 0.$$

Rotation Matrix

- Orthogonal matrix $R^T R = I$
 - Right-handed $\hat{x}_b \times \hat{y}_b = \hat{z}_b$
 - Left-handed $\hat{x}_b \times \hat{y}_b = -\hat{z}_b$
- $$R = [\hat{x}_b \quad \hat{y}_b \quad \hat{z}_b] = \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix}$$

Determinant of a 3x3 matrix M

$$\det M = a^T (b \times c) = c^T (a \times b) = b^T (c \times a)$$

$$\det R = \pm 1 \quad \text{does not change the number of independent continuous variables}$$

$$\det R = 1 \quad \text{Right-handed frames only}$$

SO(n): Special Orthogonal Group

- SO(n): Space of rotation matrices in \mathbb{R}^n

$$SO(n) = \{R \in \mathbb{R}^{n \times n} : RR^T = I, \det(R) = 1\}$$

- SO(3): space of 3D rotation matrices
- Group is a set G , with an operation \bullet , satisfying the following axioms:
 - Closure: $a \in G, b \in G \Rightarrow a \cdot b \in G$
 - Associativity: $(a \cdot b) \cdot c = a \cdot (b \cdot c), \forall a, b, c \in G$
 - Identity element: $\exists e \in G, e \cdot a = a, \forall a \in G$
 - Inverse element: $\forall a \in G, \exists b \in G, a \cdot b = b \cdot a = e$

Properties of Rotation Matrices




- Closure $R_1 R_2$
- Associativity $(R_1 R_2) R_3 = R_1 (R_2 R_3)$
- Identity element: identity matrix I
- Inverse element $R^{-1} = R^T$
- Not commutative $R_1 R_2 \neq R_2 R_1$

Uses of Rotation Matrices

- Represent a rotation
- Change the reference frame
- Rotate a vector or a frame

Representing a Rotation

- R_{sc} frame {c} relative to frame {s}



$$R_{ac} = \begin{bmatrix} 0 & -1 & 0 \\ 0 & 0 & -1 \\ 1 & 0 & 0 \end{bmatrix}$$

$$R_{ca} = \begin{bmatrix} 0 & 0 & 1 \\ -1 & 0 & 0 \\ 0 & -1 & 0 \end{bmatrix}$$




$$R_{ac}R_{ca} = I$$

$$R_{ac} = R_{ca}^{-1}$$

$$R_{ac} = R_{ca}^T$$

Changing the Reference Frame

- Orientation of {b} in {a} R_{ab}
- Orientation of {c} in {b} R_{bc}
- Orientation of {c} in {a}



$$R_{ac} = R_{ab}R_{bc}$$

= change_reference_frame_from_{b}_to_{a} (R_{bc})

- Subscript cancel rule

$$R_{ab}R_{bc} = R_{a\cancel{b}}R_{\cancel{b}c} = R_{ac} \quad R_{ab}p_b = R_{a\cancel{b}}p_{\cancel{b}} = p_a$$


Rotating a Vector or a Frame

- Rotate frame $\{c\}$ about a unit axis $\hat{\omega}$ by θ to get frame $\{c'\}$

$$R = R_{sc'}$$

- Rotation operation

$$R = \text{Rot}(\hat{\omega}, \theta)$$



Rotating a Vector or a Frame

$$\text{Rot}(\hat{x}, \theta) = \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos \theta & -\sin \theta \\ 0 & \sin \theta & \cos \theta \end{bmatrix} \quad \text{Rot}(\hat{y}, \theta) = \begin{bmatrix} \cos \theta & 0 & \sin \theta \\ 0 & 1 & 0 \\ -\sin \theta & 0 & \cos \theta \end{bmatrix}$$

$$\text{Rot}(\hat{z}, \theta) = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix}$$

Rotating a Vector or a Frame

$$\hat{\omega} = (\hat{\omega}_1, \hat{\omega}_2, \hat{\omega}_3)$$

$$\text{Rot}(\hat{\omega}, \theta) =$$

$$\begin{bmatrix} c_\theta + \hat{\omega}_1^2(1 - c_\theta) & \hat{\omega}_1\hat{\omega}_2(1 - c_\theta) - \hat{\omega}_3s_\theta & \hat{\omega}_1\hat{\omega}_3(1 - c_\theta) + \hat{\omega}_2s_\theta \\ \hat{\omega}_1\hat{\omega}_2(1 - c_\theta) + \hat{\omega}_3s_\theta & c_\theta + \hat{\omega}_2^2(1 - c_\theta) & \hat{\omega}_2\hat{\omega}_3(1 - c_\theta) - \hat{\omega}_1s_\theta \\ \hat{\omega}_1\hat{\omega}_3(1 - c_\theta) - \hat{\omega}_2s_\theta & \hat{\omega}_2\hat{\omega}_3(1 - c_\theta) + \hat{\omega}_1s_\theta & c_\theta + \hat{\omega}_3^2(1 - c_\theta) \end{bmatrix}$$

$$s_\theta = \sin \theta \quad c_\theta = \cos \theta$$


$$\text{Rot}(\hat{\omega}, \theta) = \text{Rot}(-\hat{\omega}, -\theta)$$

Rotating a Vector or a Frame

- $\{b\}$ in $\{s\}$ R_{sb}
- Rotate $\{b\}$ with

$$\text{Rot}(\hat{\omega}, \theta)$$

$\hat{\omega}$ represented in $\{s\}$ or $\{b\}$?



$$R_{sb'} = \text{rotate_by_}R\text{_in_}\{s\}\text{_frame} (R_{sb}) = RR_{sb}$$

$$R_{sb''} = \text{rotate_by_}R\text{_in_}\{b\}\text{_frame} (R_{sb}) = R_{sb}R$$

To rotate a vector $v' = Rv$

Summary

- Reference frames
- Rigid-body motions in 2D
- Rigid-body motions in 3D
 - Rotation matrices
- Uses of Rotation Matrices
 - Represent a rotation
 - Change the reference frame
 - Rotate a vector or a frame

Further Reading

- Chapter 3 in Kevin M. Lynch and Frank C. Park. Modern Robotics: Mechanics, Planning, and Control. 1st Edition, 2017
- Quaternion and Rotations, Yan-Bin Jia, <https://graphics.stanford.edu/courses/cs348a-17-winter/Papers/quaternion.pdf>
- Introduction to Robotics, Prof. Wei Zhang, OSU, Lecture 3, Rotational Motion, <http://www2.ece.ohio-state.edu/~zhang/RoboticsClass/index.html>