

The logo of The University of Texas at Dallas, featuring a circular seal with the letters 'UTD' in the center, the text 'THE UNIVERSITY OF TEXAS AT DALLAS' around the perimeter, and 'EST. 1969' at the bottom. Two stars are positioned on either side of the 'EST. 1969' text.

Forward Kinematics and Denavit-Hartenberg Parameters



CS 6301 Special Topics: Introduction to Robot Manipulation and Navigation

Professor Yu Xiang


The University of Texas at Dallas

Forward Kinematics

- Forward kinematics of a robot: calculation of the position and orientation of its end-effector from its joint coordinates θ
- Recall robot links and joints



Forward Kinematics




- End-effector frame {4}
- Joint angles $(\theta_1, \theta_2, \theta_3)$
- Position and orientation of the end-effector frame

$$\begin{aligned}x &= L_1 \cos \theta_1 + L_2 \cos(\theta_1 + \theta_2) + L_3 \cos(\theta_1 + \theta_2 + \theta_3), \\y &= L_1 \sin \theta_1 + L_2 \sin(\theta_1 + \theta_2) + L_3 \sin(\theta_1 + \theta_2 + \theta_3), \\ \phi &= \theta_1 + \theta_2 + \theta_3.\end{aligned}$$

Forward kinematics of a 3R planar open chain.

Forward Kinematics



Forward kinematics of a 3R planar open chain.

- General cases
 - Attaching frames to links
 - Using homogeneous transformations

$$T_{04} = T_{01}T_{12}T_{23}T_{34}$$

$$T_{01} = \begin{bmatrix} \cos \theta_1 & -\sin \theta_1 & 0 & 0 \\ \sin \theta_1 & \cos \theta_1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \quad T_{12} = \begin{bmatrix} \cos \theta_2 & -\sin \theta_2 & 0 & L_1 \\ \sin \theta_2 & \cos \theta_2 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$T_{23} = \begin{bmatrix} \cos \theta_3 & -\sin \theta_3 & 0 & L_2 \\ \sin \theta_3 & \cos \theta_3 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \quad T_{34} = \begin{bmatrix} 1 & 0 & 0 & L_3 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$T_{i-1,i}$ Depends only on the joint variable θ_i

Forward Kinematics

- Method 1: uses homogeneous transformations
 - Need to define the coordinates of frames
 - Denavit-Hartenberg Parameters, Northwestern Engineering's legacy in robotics started in the 1950s when Dick Hartenberg, a professor, and Jacques Denavit, a PhD student, developed a way to represent mathematically how mechanisms move <https://robotics.northwestern.edu/history.html>
- Method 2: uses screw-axis representations of transformations
 - No need to define frame references
 - Next lecture

Denavit-Hartenberg Parameters


- Attach reference frames to each link of an open chain
- Derive forward kinematics using the relative displacements between adjacent line frames
- For a chain with n 1DOF joints, $0, \dots, n$
 - The ground link is 0
 - The end-effect frame is attached to link n

$$T_{0n}(\theta_1, \dots, \theta_n) = T_{01}(\theta_1)T_{12}(\theta_2) \cdots T_{n-1,n}(\theta_n)$$

$$T_{i,i-1} \in SE(3)$$

Denavit-Hartenberg Parameters

- Assigning link frames



- \hat{z}_i -axis coincides with joint axis i
- \hat{z}_{i-1} -axis coincides with joint axis $i-1$
- Origin of the link frame
 - Find the line segment that orthogonally intersects both the joint axes
 - Origin of frame $\{i-1\}$ is the intersection of the line and the joint axis $i-1$
- \hat{x} -axis in the direction of the mutual perpendicular line pointing from $(i-1)$ -axis to i -axis
- \hat{y} -axis given by $\hat{x} \times \hat{y} = \hat{z}$


Denavit-Hartenberg (D-H) Parameters

- Link length: the length of the mutual perpendicular line a_{i-1}
 - Not the actual length of the physical link

- Line twist α_{i-1}
the angle from \hat{z}_{i-1} to \hat{z}_i , measured about \hat{x}_{i-1}

- Line offset d_i
 - Distance from the intersection to the origin of the link-i frame

- Joint angle ϕ_i
the angle from \hat{x}_{i-1} to \hat{x}_i , measured about the \hat{z}_i -axis



Rotation angle is positive counterclockwise, Negative clockwise

D-H Parameters


- For an open chain with n 1DOF joints, $4n$ D-H parameters
- For an open chain with all joints revolute
 - Link lengths a_{i-1}
 - Link twists α_{i-1} Constants
 - Link offsets d_i
- Joint angle parameters are the joint variables ϕ_i

D-H Parameters

- When adjacent revolute joint axes intersect
 - No mutual perpendicular line
 - Link length 0
 - \hat{x}_{i-1} perpendicular to the plane spanned by \hat{z}_{i-1} and \hat{z}_i
- When adjacent revolute joint axes are parallel
 - Many possibilities for a mutually perpendicular line
 - Choose the one that is most physically intuitive and results in many zero parameters as possible

D-H Parameters

- Prismatic joints



- \hat{z}_i -axis positive direction of translation
- d_i link offset is the joint variable
- ϕ_i joint angle is constant
- \hat{x} -axis in the direction of the mutual perpendicular line pointing from (i-1)-axis to i-axis
- \hat{y} -axis given by $\hat{x} \times \hat{y} = \hat{z}$


Forward Kinematics with D-H Parameters

- Link frame transformation

$$T_{i-1,i} = \text{Rot}(\hat{x}, \alpha_{i-1}) \text{Trans}(\hat{x}, a_{i-1}) \text{Trans}(\hat{z}, d_i) \text{Rot}(\hat{z}, \phi_i)$$


$$= \begin{bmatrix} \cos \phi_i & -\sin \phi_i & 0 & a_{i-1} \\ \sin \phi_i \cos \alpha_{i-1} & \cos \phi_i \cos \alpha_{i-1} & -\sin \alpha_{i-1} & -d_i \sin \alpha_{i-1} \\ \sin \phi_i \sin \alpha_{i-1} & \cos \phi_i \sin \alpha_{i-1} & \cos \alpha_{i-1} & d_i \cos \alpha_{i-1} \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$\text{Rot}(\hat{z}, \phi_i) = \begin{bmatrix} \cos \phi_{i-1} & -\sin \phi_{i-1} & 0 & 0 \\ \sin \phi_{i-1} & \cos \phi_{i-1} & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \quad \text{Trans}(\hat{z}, d_i) = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix}$$



$$\text{Trans}(\hat{x}, a_{i-1}) = \begin{bmatrix} 1 & 0 & 0 & a_{i-1} \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \quad \text{Rot}(\hat{x}, \alpha_{i-1}) = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & \cos \alpha_{i-1} & -\sin \alpha_{i-1} & 0 \\ 0 & \sin \alpha_{i-1} & \cos \alpha_{i-1} & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Forward Kinematics with D-H Parameters




A 3R spatial open chain in its zero position

D-H Parameters

i	α_{i-1}	a_{i-1}	d_i	ϕ_i
1	0	0	0	θ_1
2	90°	L_1	0	$\theta_2 - 90^\circ$
3	-90°	L_2	0	θ_3

Forward Kinematics with D-H Parameters




D-H Parameters

i	α_{i-1}	a_{i-1}	d_i	ϕ_i
1	0	0	0	θ_1
2	90°	0	0	θ_2
3	0	L_2	0	$\theta_3 + 90^\circ$
4	90°	0	θ_4	0

An RRRP spatial open chain in its zero position

Forward Kinematics with D-H Parameters



D-H Parameters

i	α_{i-1}	a_{i-1}	d_i	ϕ_i
1	0	0	0	θ_1
2	90°	0	0	θ_2
3	0	L_1	0	$\theta_3 + 90^\circ$
4	90°	0	L_2	$\theta_4 + 180^\circ$
5	90°	0	0	$\theta_5 + 180^\circ$
6	90°	0	0	θ_6

A 6R spatial open chain in its zero position

Summary

- Forward kinematics
- Denavit-Hartenberg Parameters

Further Reading

- Chapter 4 and Appendix C in Kevin M. Lynch and Frank C. Park. Modern Robotics: Mechanics, Planning, and Control. 1st Edition, 2017.
- J. Denavit and R. S. Hartenberg. A kinematic notation for lower-pair mechanisms based on matrices. ASME Journal of Applied Mechanics, 23:215-221, 1955.